

KINDRED

Waste Disposers

The Convenience of In-Home Warranties

Why choose a Kindred waste disposer?

Because you can be sure that any product that bears the name Kindred will deliver years of trouble free service.


And this means peace of mind is reinforced with the Kindred in-home warranty.

Kindred in-home service warranty covers all replacement parts and labor to correct defects in material and workmanship for the published warranty period, from the date of purchase.

If service is requested during the warranty period, Kindred will replace the disposer in the customer's home at no charge.

This kind of warranty demonstrates Kindred's commitment to quality.

And this is one of the reasons that Kindred is the name that plumbers have come to trust for more than 50 years.

Kindred Waste Disposers are  certified.



Kindred Waste Disposers

	KWD50	KWD50A	KWD75A	KWD100A
Horsepower	1/2	1/2	3/4	1
RPM	2600	2600	2700	2800
Warranty	5 years	5 years	10 years	10 years
Feed	Continuous	Continuous	Continuous	Continuous
Mounting System	Easy Mount	Easy Mount	Easy Mount	Easy Mount
Grinding Ring	Galvanized	Stainless	Stainless	Stainless
Turntable	Galvanized	Stainless	Stainless	Stainless
Impellers	Stainless	Stainless	Cast Stainless	Cast Stainless
Power Connection	Power Cord	Power Cord	Power Cord	Power Cord
Shell	—	Insulated	Insulated	Insulated

Waste Disposers

Kindred Waste Disposers Kitchen Helpers

A Kindred food waste disposer will simplify your life. Just turn on the cold water at the sink, empty food waste into the disposer opening, and switch on the unit with an on/off wall switch, or a mounted air switch (see our accessories). In either case, the idea is that food may be continuously fed into the disposer while it is running. It only takes seconds. A spinning metal plate pushes the food waste against a tough grinding ring fixed to the wall of the disposer chamber. The waste is ground safely and quickly into fine particles which then pass through small holes in the plate, and are flushed out in suspension through the plumbing drain lines.

Disposer Performance Information

A waste disposer simplifies cleanup after the meal. Food scraps can be rinsed off the plate into the disposer, right at the sink.

A waste disposer helps to sanitize your kitchen sink area. Food waste is flushed down the drain.

And since food has been eliminated, there is no bad odor in the waste bin.

A waste disposer decreases the amount of garbage that you need to bag.

And that means you have done your part for the environment. There will be less waste at the local landfill site.

Kindred Air Switch Accessory for Continuous Feed

The Kindred air switch is an alternative to a wall mounted electrical switch.

It is an easily installed air actuated on/off control for the waste disposer that may be mounted on the counter near the sink, or in an existing hole drilling on the sink ledge.

This accessory is available in Chrome or Satin Nickel and requires WD9088 controller.



350 Campus Drive, Suite 500, Hatfield, PA 19440
800.626.5771 fax 800.789.6201 www.frankeconsumerproducts.com